

DISCLAIMERS

- Do not place Turtle in salt water (ocean).
- Do not use Turtle in sandy environment (beach).
- After using Turtle in chlorinated water (swimming pool), immediately rinse with clean water, wipe with a clean cloth or paper towel, and set to dry before storage.
- Turtle must be fully assembled (i.e. battery door must be closed) before placing in water.
- Do not try to touch or insert objects into propeller, as propeller spins at a high speed and may cause damage.
- Avoid placing this toy close to hair as hair might become tangled in the moving parts.

WARNING: NOT SUITABLE FOR CHILDREN UNDER 3 YEARS. DO NOT TRY TO TOUCH OR INSERT OBJECTS INTO THE PROPELLER. KEEP HAIR AND LOOSE CLOTHING AWAY FROM MOVING PARTS. NOT A BATH TOY. CAUTION: ADULT SUPERVISION ENCOURAGED FOR YOUNG CHILDREN. IMPORTANT: DROPPING LITTLE LIVE PETS™ TOY MAY CAUSE DAMAGE THAT PREVENTS LITTLE LIVE PETS™ FUNCTIONS. READ ALL INSTRUCTIONS CAREFULLY BEFORE USING PRODUCT.

WARNING! CHOKING HAZARD.
Not suitable for children under 36 months. Choking hazard (small parts). Parts are not intended for use as toys. Not intended for children younger than the age recommended on this package. At the end of the useful life of this product, do not dispose in normal household waste. Please refer to the recycling part for the recovery and recycling of electrical/electronic equipment. Product specifications, colour and contents may vary from those illustrated. Please refer to the user manual for more information. Visit our website for more details for further reference as they contain important information.

WARNING! Risk of entanglement.
Keep hair away from the toy.

Item: Little Live Pets Lil' Turtle
S8 Single Pack (2 Asst'd)
Item Number: 26328
Age Grade: 3 years plus

UK
CA



FCC STATEMENT

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

WWW.LITTLELIVEPETS.COM

FOR AGES
5+

**Little
Live
Pets™**



One Turtle included, other Turtle is sold separately.

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.



CHARACTER

moose™


INSTRUCTION BOOKLET

YOUR TURTLE


ON-OFF Button (Press to turn on/off)

Battery compartment


Propeller



Your Turtle can walk on land...





AND it can swim in water!



BATTERIES

Requires 1 x AAA/LR03 Battery.
(Batteries Not Included)

- Alkaline batteries recommended.
- Rechargeable batteries must only be recharged under adult supervision.
- Rechargeable batteries must be removed from the toy before recharging.
- Non-rechargeable batteries must not be recharged.
- Different types of batteries, or new/and used batteries must not be mixed.
- Only batteries of the same or equivalent type as recommended should be used.
- Batteries should be replaced by an adult.
- Batteries must be inserted following the correct polarity.
- Exhausted batteries should be removed from the product.
- The supply terminals must not be short-circuited.
- Batteries should be removed from the product when not in use.
- Do not dispose of batteries in fire.



TROUBLESHOOTING

Turtle is walking or swimming very slowly.

Battery may be flat. Replace with a fresh battery.

Turtle is not turning on when on/off button is pressed.

Try to press the button harder all the way to the bottom then release when you hear a click sound.

Battery may be flat. Replace with a fresh battery.

