



INSTRUCTIONS FOR USE

Please keep this instructions for future reference

BATTERY INSERTION AND REPLACEMENT

1. Unscrew the top part to remove the battery lid.
 2. Insert 3x1.5V AAA (LR03) batteries (included), negative end (-) first into battery compartment. Match positive (+) and negative (-) signs as shown in Image Batteries may leak if improperly installed. Remove the batteries when toy is not used for an extended period of time.
 3. To replace lid, fit tabs into slots and screw closed
- Diagram to show how to open the battery door and insert batteries.

BATTERY SAFETY INFORMATION

Only adults should install and replace batteries. Insert batteries correctly. Match positive (+) and negative (-) signs as shown in image. Alkaline batteries are recommended for best performance. Rechargeable batteries are not recommended. If rechargeable batteries are used, they are only to be charged under adult supervision. Rechargeable batteries are to be removed from the product before they are charged. Do not recharge non-rechargeable batteries. Only use batteries of the same or equivalent type that are recommended for use. Do not mix different types of batteries: alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium). Do not mix old and new batteries. Remove dead or exhausted batteries. Remove the batteries during long periods of non-use. Always remove exhausted batteries from the toy. Battery leakage and corrosion can damage this product. Dispose of batteries safely. Recycle where available. Do not dispose of batteries in a fire or attempt to open the outer casing. Never short-circuit the battery terminals. Do not immerse-operated toys in water. Wipe clean only.

ELECTRONIC WASTE (Including batteries)

The wheelite bin symbol indicates the product and batteries must not be disposed of in domestic waste as they contain substances damaging to the environment and health. Please use collection points or recycling facilities.

Manufactured by:
sol
Room 507/10ng, Ngia Hwey Centre
4 Kiah West St, East Hong Kong
Kowloon, Hong Kong

© 2016/2020

Imported by:
Toy Zone Trade - Ltd.
C/ Avenida Urdiales, 80, 2º Edifio
33001 Gijón, Asturias, Spain
sol.com

Distributed by:
Character Options Ltd.
The Character Centre
Leeds, Oldham, Old & Salford, UK


Customer Service Department
Tel No: **0161 633 9808**
Made in China

www.character-online.co.uk

WARNING! CHOKING HAZARD.

Not suitable for children under 36 months. Choking hazard (small parts). Please remove all packaging accessories before giving the product to a child. Use with discretion. The product is not suitable for children under 36 months. Do not use if damaged. Check the age of the child. Do not use if damaged. Check with your local authority or responsible disposal centre and submit to the collection point for the recovery and recycling of electrical electronic equipment. Product specifications, colour and content may vary from those illustrated.

IMPORTANT: Please retain packaging/instructions and purchase details for future reference as they contain important information.



Requires 3 x AAA Batteries. (Demonstration Batteries Included).

- Alkaline batteries recommended.
- Rechargeable batteries must only be recharged under adult supervision.
- Rechargeable batteries must be removed from the toy before recharging.
- Non-rechargeable batteries must not be recharged.
- Different types of batteries or new and used batteries must not be mixed.
- Only batteries of the same or equivalent type as recommended should be used.
- Batteries should be replaced by an adult.
- Batteries must be inserted following the correct polarity.
- Exhausted batteries should be removed from the product.
- The supply terminals must not be short-circuited.
- Batteries should be removed from the product when not in use.
- Do not dispose of batteries in fire.



RECYCLING OUR PRODUCTS

All our products and packaging is designed with easy and safe recycling in mind. For information on the National Recycling Strategy and the recycling logo, see the back of product, please visit www.recycle.org.uk or call the freephone number the answer to your UK recycling questions.



Item: **JIGGLY KOALA - ASSORTED COLOUR**
Item Number: **JPO07**
Age Grade: **4 years plus**

BATTERY RECYCLING INFORMATION

Help the environment by disposing of batteries responsibly. The wheelite bin symbol indicates that batteries must not be disposed of in domestic waste as they contain substances which can be damaging to the environment and health. Please remove exhausted batteries from the product and use designated collection points or recycling facilities when disposing of batteries.



