

Get most stretch fun by pulling Scooby's hands and feet.



# SCOOBY-DOO!

## Stretch Scooby



SCOOBY-DOO and all related characters and likenesses are trademarks of WARNER BROS. ENTERTAINMENT CO. TM & © LUBEI (USA)

### WARNING! CHOKING HAZARD.

Not suitable for children under 36 months. Choking hazard (small parts). Please remove all packaging attachments before giving this product to a child. Please use discretion if making purchases for children younger than the age recommended on this package. Product specifications, colour and contents may vary from those illustrated.

**IMPORTANT:** For more details, please refer to the important information on the inside of the packaging.



Manufactured by  
Changzhou Lubei Toys Co., Ltd.  
Lubei Toys Co., Ltd.  
Changzhou City, Jiangsu Province  
to meet CE and EN71 standards  
Made in China

[www.characteronline.co.uk](http://www.characteronline.co.uk)

Developed, engineered and produced by JAKKS-PAL Switzerland.

### RECYCLING OUR PRODUCTS

All our products and packaging is designed with easy and clear recycling instructions. National Recycling Strategy for recycling in the UK. Please see the recycling logo on this pack or product please use the instructions to ensure you are recycling correctly. For more information please visit [www.recycling.gov.uk](http://www.recycling.gov.uk)



### CONTAINS: Non-toxic, food grade plastic solution

### CLEANING INSTRUCTIONS

Wipe clean with a damp cloth.

### IMPORTANT

Your stretch figure is tough, but its skin can be injured... so play with care.

Excessive abuse can hurt your stretch figure, and we reserve the right to refuse return of any toys subject to such abuse.

**NOTE:**

Art No: 05397-021116-V1B

# WOW! IT'S S-T-R-E-T-C-H-Y!!



- ⚠️ Your stretch figure will break if you pull him too far.
- ⚠️ Excessive stretching could result in damage to the toy.
- ⚠️ When your figure is cold, he is more difficult to stretch. As you hold him and stretch him carefully, he "warms up," and will be easier to stretch.
- ⚠️ Do not pull your figure too far but stretching him too far can break your toy. DO NOT OVER STRETCH!

**MAX**  
Stretch up to 125cm/49inches!  
**STRETCH!**

# IMPORTANT NOTE:

## ALWAYS PLAY SAFELY!

- ⚠️ Do not wrap or tie your figure around any person's head, arm or leg.
- ⚠️ Your stretch figure is **NOT** indestructible!
- ⚠️ To stretch him, hold only his hands and feet.
- ⚠️ **DO NOT** pull from shoulders and upper arms.
- ⚠️ **DO NOT** puncture or bite - keep him away from sharp objects and pets.
- ⚠️ **DO NOT** pull his head, if it comes off warm the head in warm tap water for 5 minutes and then carefully pop back onto the neck, (Ask an adult for help).
- ⚠️ **DO NOT** tie knots into arms or legs.
- ⚠️ **KEEP** him away from intense heat.
- ⚠️ **DO NOT** leave your stretch figure out in the sun.
- ⚠️ **DO NOT** play when wet.
- ⚠️ **WARNING** - Avoid rubbing or scratching painted decoration to keep your toy in good condition for longer.

If your figure breaks and leaks onto clothing, upholstery or carpeting, the non-toxic, food grade glucose solution filling can be removed by rubbing the area with a sponge and warm water.

**PLEASE NOTE:**  
Your stretch Scooby may not appear full due to settling during shipping.  
This is normal. Simply pull it back into shape with a few stretches.