


and feet.



WARNING! CHOKING HAZARD.

Not suitable for children under 36 months. Choking hazard (small parts). Please remove all packaging attachments before giving this product to children. Age restriction is for children over 3 years. For children under 3 years, please refer to the recommended age on this package. Product specifications, colour and contents may vary from those illustrated.

IMPORTANT! Please retain packaging/instructions and purchase details for future reference as they contain important information.



RECYCLING OUR PRODUCTS

For information on the National Recycling Strategy and how to recycle, please visit www.recycling.gov.uk. For information on the National Recycling Strategy visit www.recycling.gov.uk - where you will find the latest information on recycling.



CONTAINS: Non-toxic, lead free, phthalate free

CLEANING INSTRUCTIONS: Wipe surface with warm soapy water.



Character Online Ltd.
Customer Services Team
The Character Online Centre
100, Old Street, London, EC1A 1DF
Tel: 0161 613 9888
Email: info@character-online.co.uk
United Kingdom

www.character-online.co.uk

Developed, engineered and produced exclusively by Jibberjelly Switzerland.

Licensed By:



Hasbro Entertainment Group
100 Main Street
Franklin, MA 01717
USA
© 2011 Hasbro




Licensed By:



Hasbro Entertainment Group
100 Main Street
Franklin, MA 01717
USA
© 2011 Hasbro

THE ORIGINAL
**STRETCH
ARMSTRONG**



WOW! IT'S S-T-R-E-T-C-H-Y!!






IMPORTANT NOTE:

ALWAYS PLAY SAFELY! YOUR STRETCH FIGURE IS NOT INDESTRUCTABLE!

- Do not wrap or tie your figure around any person's head, arm or leg.
- Take care not to tie knots too tightly or knot individual limbs.
- To stretch him, hold only his hands and feet.
- DO NOT** pull from shoulders and upper arms.
- DO NOT** puncture or bite - keep him away from sharp objects and pets.
- DO NOT** pull his head, if it comes off, warm the head in warm tap water for 5 minutes and then carefully pop back onto the neck. (Ask an adult for help).
- DO NOT** twist his legs or waist.
- KEEP him away from intense heat.
- DO NOT** leave your stretch figure out in the sun.
- WARNING** - Avoid rubbing or scratching painted decoration to keep your toy in good condition for longer.

- Your stretch figure will break if you pull him too far.
- Excessive stretching could result in damage to the toy.
- FORGET THE COLD OR THE HEAT!**
Stretch doesn't like extreme cold or hot conditions. Keep him at room temperature and he'll be alright. Outside is okay, if the temperature is about 22°C (72°F) or above.
- When your figure is cold, he is more difficult to stretch. As you hold him and stretch him carefully, he "warms up," and will be easier to stretch. Alternatively, you can put him in a bowl of warm water to soften up.
- Do not pull your figure too far, stretching him too far can break your toy. **DO NOT OVER STRETCH!**



If your figure breaks and leaks onto clothing, upholstery or carpeting, the non-toxic, food grade glucose solution filling can be removed by rubbing the area with a sponge and warm water.

STRETCH!	
MAX	ARMSTRONG up to 68cm/27inches
	FETCH up to 36cm/14inches
	OCTOPUS up to 80cm/31inches

PLEASE NOTE:
Your STRETCH FIGURE may not appear full due to settling during shipping.
This is normal. Simply pull it back into shape with a few stretches.