

CAUTIONS!

ADULT SUPERVISION REQUIRED ESPECIALLY FOR YOUNG CHILDREN. USE WITH CAUTION. Skill is required to avoid falls or

ADULT SUPERVISION REQUIRED ESPECIALLY FOR YOUNG CHILDREN. USE WITH CAUTION. Skill is required to avoid fall collisions that may cause injury to the user or third parry.

SAFE RIDING AREA, SO ON OTH YAT NEAR ROADS, PUBLIC FOOTPATHS, STEPS, PONDS, SWIMMING POOLS OR ANY OTHER AREA HAZARDOUS TO THIS KIND OF PLAY ACTIVITY. Play in a clear area away from obstacles, other people and animals. Play area PMUSTs be free from sonce and other sharp objects.

PERSONAL PROTECTIVE EQUIPMENT. Helmer, glowes, knee-pads, elbow pads, etc are recommended to be used when playing, ALWATS wear sport shoes when playing with this product.

PLEASE READ THE INSTRUCTIONS FOR THE PROPER USE OF THIS PRODUCT.

DO NOT MAKE ALTERATIONS ON THIS PRODUCT.

FOR BEST RESULTS-

Ball Inflation and Handle strap length for height adjustment MUST be done by an adult.

Item: Stay Active Hip Hoppa Item Number: 07640 Age Grade: 6 years plus



Tel No: 0161 633 9808 Made in China

PROXY A/S 4. 3<sup>rd</sup> Floor DK-1123

Art No: 06382-110222-VIA

RECYCLING OUR PRODUCTS
All our product and packaging is designed with easy All our product and packaging is designed with easy and safe recycling in mind. For information on the National Recycling Strategy and the recycling logo on this pack or product please visit — www.Recycle-More.co.uk — where you will find ers to your UK recycling qu



# Remember to play safely:

- Always wear sport or gym shoes. Never use Hip Hoppa with bare feet.
- · For added safety, protective equipment is recommended (helmet, knee and elbow pads).
- Use Hip Hoppa in a clear area away from obstacles, other people and animals.
- Check the play area is free from stones and other sharp objects.
- · Do not use Hip Hoppa on public footpaths, near roads, steps, ponds, swimming pools or any other hazards.
- Do not swing Hip Hoppa around by the strap, use only as intended.

## BALL INFLATION


Performance may vary due to the weight of the user. Inflate or deflate the ball to enhance your performance.



For Best Result: Suggested ball inflation pressure: approx.90kPa / 13.05 PSI Caution! Do not exceed Max. pressure 130 kPa / 18.85 PSI

Use a bicycle pump (not included) and relevant adapter (not included) to inflate. The valve is found on the underside of the base. Over inflation will cause damage to the ball.

If ball damaged, please discard the product as it will be result in sudden collapse of the product so as loss of balance and possible injury.




If the handle is too high or too low, adjust the strap by pushing the buckle up to shorten, or down to lengthen.



When in use, the handle of the Hip Hoppa needs to be held at thigh height.


Please follow this strap length adjustment height to avoid result in loss of balance and possible injury. If the strap damaged, please



Place one foot on the base, holding the handle tight and keeping the strap taut. The Hip Hoppa will dip to one side. Bring your other foot onto the base, keeping the strap taut and immediately start hopping.



When you want to stop hopping, reduce to small controlled hops on the spot.



In one movement quickly take both feet off the base to land with one foot either side of the Hip Hoppa. Do not attempt to dismount one foot at a time as this will result in loss of balance and possible injury.

LOAD CAPACITY



Hip Hoppa is not designed to carry heavy loads. Do not exceed 50kg.

